

RHEOBYK-R 605 SG

Liquid rheology additive for plastic applications such as vinyl ester and epoxy resins, unsaturated polyester resins, and gel coats to reinforce the rheological effectiveness of pyrogenic silica. Incorporation of the fumed silica is made easier, separation is prevented, and the thixotropic behavior increased or stabilized.

Product data

Composition

Solution of polyhydroxycarboxylic acid amides

Typical properties

The values indicated in this data sheet describe typical properties and do not constitute specification limits.

Density (20 °C):	0.93 g/ml
Non-volatile matter (20 min, 150 °C):	52 %
Flash point:	29 °C
Refractive index (20 °C):	1.496
Gardner color number:	< 10

Storage and transportation

Separation or turbidity may occur. Mix well before use. Product efficiency is not influenced.

Applications

Thermosets

Special features and benefits

RHEOBYK-R 605 SG is used as a thixotropic-reinforcing additive in unsaturated polyester resins, epoxy and polyurethane systems that already contain pyrogenic silica or organophilic phyllosilicates (organoclays) as rheology additives. The additive reinforces the three-dimensional network structure of the silica or phyllosilicates through additional bridges, thereby enhancing the thixotropy. For this reason, it achieves sufficiently high anti-sagging properties with improved leveling and air release properties, even with low quantities of silica or phyllosilicates.

Low quantities of RHEOBYK-R 605 SG (5 % based on the silica) stabilize silica in laminating resins, thereby preventing resin separation during storage.

In vinyl ester resins, RHEOBYK-R 605 SG activates hydrophilic, pyrogenic silica.

The additive can be used in various resins, including polyols, to prevent fillers settling during storage.

In polyols, RHEOBYK-R 605 SG is used to stabilize molecular sieves such as zeolite.

Recommended levels

Additive quantity (as supplied) based on the

pyrogenic silica in vinyl ester resins:	20–50 %
pyrogenic silica in other resins:	10–30 %
organophilic phyllosilicates (organoclays):	5–20 %
inorganic fillers:	0.5–2 %

The above recommended levels can be used for orientation. The optimum dosage should be determined by application-related test series.

Incorporation and processing instructions

The additive should be added to the resin whilst stirring before incorporating the silica, phyllosilicates or fillers. Post-addition of the additive is also possible.

Adhesives and sealants**Special features and benefits**

RHEOBYK-R 605 SG is a thixotropic-reinforcing additive for polyurethane and acrylate resins that are rendered thixotropic using pyrogenic silica or organophilic phyllosilicates (organoclays). It reinforces the hydrogen bonds of the silica and phyllosilicates, resulting in increased thixotropy. For this reason, it achieves sufficiently high anti-sagging properties with improved leveling and air release properties even with low quantities of silica or phyllosilicates.

Recommended levels

10–30 % additive (as supplied) based upon the pyrogenic silica or organophilic phyllosilicates.

The above recommended levels can be used for orientation. The optimum dosage should be determined by application-related test series.

Incorporation and processing instructions

The additive should be added to the resin before incorporating the silica/phyllosilicates whilst stirring. Post-addition is also possible.



Ihr lokaler
Kontakt

BYK-Chemie GmbH
Abelstraße 45
46483 Wesel
Deutschland
Tel +49 281 670-0
Fax +49 281 65735

info@byk.com
www.byk.com

ADD-MAX®, ADD-VANCE®, ANTI-TERRA®, AQUACER®, AQUAMAT®, AQUATIX®, BENTOLITE®, BYK®, BYK-AQUAGEL®, BYK-DYNWET®, BYK-MAX®, BYK®-SILCLEAN®, BYKANOL®, BYKCARE®, BYKETOL®, BYKJET®, BYKO2BLOCK®, BYKONITE®, BYKOPLAST®, BYKUMEN®, CARBOBYK®, CERACOL®, CERAFAK®, CERAFLOUR®, CERAMAT®, CERATIX®, CLAYTONE®, CLOISITE®, DISPERBYK®, DISPERPLAST®, FULACOLOR®, FULCAT®, GARAMITE®, GELWHITE®, HORDAMER®, LACTIMON®, LAPONITE®, MINERPOL®, NANOBYK®, OPTIBENT®, OPTIFLO®, OPTIGEL®, POLYAD®, PRIEX®, PURABYK®, PURE THIX®, RECYCLOBLEND®, RECYCLOBYK®, RECYCLOSSORB®, RECYCLOSTAB®, RHEOBYK®, RHEOCIN®, RHEOTIX®, SCONA®, SILBYK®, TIXOGEL® und VISCOBYK® sind eingetragene Warenzeichen der BYK Gruppe.

Die vorstehenden Angaben entsprechen unserem derzeitigen Kenntnisstand. Sie beschreiben abschließend die Beschaffenheit unserer Produkte, stellen jedoch keine Garantie im Rechtssinne dar. Vor der Verwendung unserer Produkte obliegt es dem Verwender, die Qualität und Eignung unserer Produkte für die von ihm geplante Verarbeitung und Anwendung zu prüfen. Dies gilt auch für eine etwaige Verletzung von Schutzrechten Dritter. Wir behalten uns Änderungen der vorstehenden Angaben aufgrund des technischen Fortschritts und betrieblicher Weiterentwicklungen vor.

Diese Ausgabe ersetzt alle bisherigen Versionen.